

Air Scrubber Owner's Manual

Model:
X-2830, X-2830U

220-240V~,50Hz



Read and save these instructions
www.xpower.com | www.tx-5.com.hk

Index: EU-1-A38
Edition: 1.1.Final


Safety Instructions

WARNING - READ AND SAVE THIS INSTRUCTIONS BEFORE USING THIS PRODUCT.

The user of electrical products may create hazards that include, but are not limited to injury, fire, electrical shock. Failure to follow these instructions may damage and/or impair its operation and void the warranty.

- Before operating, remove all packaging material and check for any damage that may have occurred during shipping or any missing items.
- Check household power supply to ensure it matches the appliance's specification.
- **DO NOT** operate any fan with a damaged cord or plug. Discard fan or return it to an authorized service facility for examination and/or repair.
- **DO NOT** run cord under carpeting. **DO NOT** cover cord with throw rugs, runners, or similar coverings. **DO NOT** route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- To reduce the risk of fire or electric shock, **DO NOT** use this appliance with any solid-state speed control device.
- **DO NOT** touch this appliance or the plug with wet hands or while standing in water.
- **DO NOT** operate the appliance in any pooled water.
- **DO NOT** use the product in areas where gasoline, paint or other flammable goods and objects are used or stored.
- **DO NOT** insert or allow objects to enter any ventilation or exhaust opening as this may damage the appliance and void the warranty.
- **DO NOT** cover the air inlet or outlet on the appliance.
- **DO NOT** direct the air flow at human faces or bodies.
- **DO NOT** allow children to play around or with this appliance.
- **AUTOMATICALLY OPERATED DEVICE** – To reduce the risk of injury, disconnect from power supply before servicing.
- Remove the power cord from the electrical receptacle by grasping and pulling on the power cord plug-end only, **DO NOT** pull the cord directly.
- **DO NOT** attempt to repair or adjust any electrical or mechanical functions of this appliance, as this may cause danger and void the warranty.
- If the appliance is damaged or it malfunctions, **DO NOT** continue to use it. Unplug the product from the electrical outlet. Refer to troubleshooting guide or contact XPOWER.
- Store in a dry area, away from exposure to sunlight, extreme temperature and humidity, or other extreme environments, when not in use.
- **DO NOT** stack more than five units of this appliance.
- An electronic instruction manual can be obtained through manufacturer's website www.xpowermfr.com.

Items Included




• Air Scrubber x 1



• Owner's Manual x 1


Parts Description

Machine



- | | | |
|------------------------------|-------------------------|--|
| (1) Air Quality Sensor Cover | (9) Rubber Sealing Ring | (17) Zinc Alloy Hinge |
| (2) Air Quality Sensor | (10) Front Housing | (18) UV Lamp Assembly (for X-2830U only) |
| (3) Rear Housing | (11) Rubber Feet | (19) Cover |
| (4) Switch Plate | (12) Power Cord | |
| (5) Capacitor | (13) Quakeproof Washer | |
| (6) Pressure Switch | (14) Transformer | |
| (7) Pressure Switch Cover | (15) Motor Holder | |
| (8) Air Quality Sensor Box | (16) Motor Assembly | |

Filters




MODEL NUMBER		X-2830	X-2830U
First Stage Filter	NFS13		
Second Stage Filter	PF13		
Third Stage Filter	CF15		
Fourth Stage Filter	HEPA50-33		
Fifth Stage Filter	-		TF12

The graph only presents the appearance of the filters. The actual sizes of filters with different part number could be slightly different. (See Page 15: Technical Specifications)

If your product(s) is not listed above, please visit www.xpower.com for more information.

Air Scrubber Introduction


- XPOWER's unique and highly innovative Air Scrubbers create a fresh and clean environment for various purposes.
- With a special designed powerful motor, XPOWER Air Scrubbers are able to provide suction in even difficult areas.
- The included filtration system can capture a wide range of compounds and prevents organism migration from location to location.



Installation and Operation Guide

Selecting a Location (Important)


- **Enclosed Area:** For optimal efficiency and longer filter lifespan, the Air Scrubber should be operated in an enclosed area. Keep all doors, windows and other outside entrances to the room closed.
- **Air Circulation:** It's suggested to have a constant efficient air circulation inside your working area. You may achieve this with XPOWER Air Mover combinations.
- **Environment Humidity:** For optimal efficiency and higher filter lifespan, the Air Scrubber should not be operated in an environment with a high relative humidity level. High humidity level could cause blockage and damage to filters.
- **Power Cord:** The power cord has a length of 4.0 meters. Select a location where the power cord can reach the power source.
- **Inlet and Outlet Orientation:** Also pay attention to the orientation of the air inlet and air outlet. Make sure the airflow won't influence any object nearby the Air Scrubber.
- **IMPORTANT:** The effectiveness of the Air Scrubber can be influenced by different factors. You may also find that installing multiple Air Scrubbers may be required for larger enclosed areas.



Exhaust Ducting

- Turn off the machine.
- Attach the ducting hose to the exhaust.

Control Panel



Buttons

Power Switch

Press to switch on / off the machine.

Running Time Value / Timer Value Switch

Press to exit timer setting mode and switch the display of the running time value / enter timer setting mode and timer value display.

Speed Control

Tap “+”/“-” to increase/decrease the desired fan speed.

Timer Control

When the display is switched to indicate the timer value, tap “+”/“-” increase / decrease the value of the timer setting.

Information

Timer Value / Running Time Value Display

This will show the value of the timer or running time. As default, it displays the running time value. When the machine is switched off, the value will be reset to zero automatically.

Fan Speed Display

This will show the speed setting of the fan. There are 5 speed settings. 5 Bars mean the machine is on the highest speed setting and 1 bar means the machine is on the lowest speed setting.

Control Panel (Continued)

Indicators

Running Time Value
Display Indicator



When this indicator illuminates, it indicates the value display is showing the value of the running time.

Filter Change Indicator Light




When the green light illuminates, it indicates the filters are under a good condition. When the red light illuminates, it indicates that the filters have exceeded the maximum capacity of particles, and the filtration efficiency has diminished. You should clean or replace the filters. (See Page 10: Filter Maintenance)

Timer Value
Display Indicator



When this indicator illuminates, it indicates the machine enters the timer setting mode and the value display is showing the value of the timer.


Air Quality Monitor



- When this monitor blinks, it indicates the Air Quality Sensor is now preparing for detection.
- The digital display will show the concentration of fine particulate matter (PM_{2.5}) in the environment in $\mu\text{g}/\text{m}^3$.
- The index light will indicate the air quality category of the environment. According to the Air Quality Index developed by the United States Environmental Protection Agency (EPA), the index light corresponds to different levels of health concern as below:


Index Light	Levels of Health Concern according to the AQI by EPA
Green / Good	Good
Orange (Yellow) / Moderate	Moderate or, Unhealthy for Sensitive Groups
Red / Poor	Unhealthy, or Very Unhealthy, or Hazardous

Transportation



Carry with Handle

Lift the Air Scrubber with the handle on the top of the housing.



Stack in Carrier

You can stack up to 5 Air Scrubbers and transport.

User Maintenance Instructions

Frequent maintenance is recommended on this appliance. Failure to follow the maintenance instructions may cause failure of the appliance and void the warranty.

Before performing any maintenance or cleaning, always disconnect the Air Scrubber from its power source.


Machine Maintenance

- When not in use, unplug, remove all the extension . Store the appliance in a dry and cool indoor place. Make sure it's out of reach of children.
- Use a damp cloth to wipe the surface of the housing. Do not clean the unit with water directly.
- Check if the grille covers are clean. Remove dirt or any other objects that could block the air inlet and air outlet.
- Do not stack more than five units of this appliance.

Filter Maintenance

To ensure the best filtration efficiency and to prevent secondary pollution of used filters, you should replace or clean the filters frequently or when the filter change light illuminates. Please follow the instructions below.

Unload the filters *(See Also Page 3: Parts Description)*



Inner Filters

Open the filter cover by releasing the latch kit on top. Unload inner filters inside.

Clean the filters *(See Also Page 4: Filters)*

- **Nylon Mesh Filters:** These filters are washable with water. Use a vacuum or clean cloth to remove loose debris. And then further clean the filter with water. Use a cloth to remove the water on the filter and dry it naturally in the air.
- **Pleated Media Filters:** This filter is not washable. Use a vacuum to remove loose debris. If filter change light still illuminates, you might need to replace the filter.
- **Carbon Filters:** This filter is not washable. Use a vacuum to remove loose debris. Lay it flat on a clean and dry surface under the sun for 3 hours. Sunshine will help remove various substance absorbed in the carbon with an appropriate temperature. If filter change light still illuminates or a decline of effectiveness is noted, you might need to replace the filter.
- **HEPA Filters:** This filter is not washable or reusable. Highly concentrated particles are captured by the HEPA filter and cleaning this filter can be hazardous to human health and contaminate the nearby environment. You must replace the filter if all the other filters are clean and however the filter change light still illuminates.

Filter storage

- When not in use for a long time, you should store the filter separately from the machine.
- Always clean the filters before storage. Place the filters in a sealed plastic bag and store it in a dry and cool indoor place.




WARNING: DISPOSAL OF FILTERS NO LONGER IN USE

The particles captured by a used filter can cause adverse human health effects and contaminate the nearby environment once the filter is exposed to the open air. Adequate personal protection equipment (PPE) is required during the whole process, for example, industry approved masks, eye protectors, gloves and coveralls. You should place the used filters in a sealed plastic bag before disposing. Follow local disposal regulations.


Reload the filters

To ensure the best efficiency and lifespan, each filter must be reloaded in a correct position, sequence and orientation.




Inner Filters

- Other filters must be loaded inside the Air Scrubber.
- See *Page 4: Filters* to check the installation sequence.



Last Stage Filter:

- On one of the side of the last stage filter, there is an EVA sealing pad around the frame.
- The last stage filter must be loaded with EVA side facing the machine housing.
- The EVA sealing pad ensures that all the air is filtered.



Tips:

- On one of the side of each filter, there is a label with an arrow showing the airflow direction.
- When placing the filter, the side with label should face up. The arrow on the label should point to the blue housing.

Troubleshooting Guide

PROBLEM	POSSIBLE CAUSE	SOLUTION
Air Scrubber does not start	No electricity.	Check for power supply.
	The power cord is not properly plugged in.	Remove and reconnect the power cord.
Unit runs but no or very low air movement	Air outlet is blocked.	Remove blockage.
	Filters are fully loaded. The filter change light illuminates.	Clean or replace the loaded filters. (See Page 10: Filter Maintenance)

If troubleshooting does not resolve your problem, please contact XPOWER or other parties authorized by XPOWER for further instructions.

Technical Specification

Machine Specification

MODEL NUMBER	X-2830	X-2830U
Voltage/ Frequency	220-240V~, 50Hz	
Motor Power	220 W	230 W
Rated Airflow	550 CFM	500 CFM
Speed Control	5 Speeds	
Off-Timer Meter	0.5 - 24 h	
Cord Length	4 m	
Unit Dimension (L) x (W) x (H)	42.2 x 26.4 x 48.0 cm	
Unit Weight	11.09 kg	11.73 kg

Filter Specification

FILTER MODEL NUMBER	Type of Filter	Size	Thickness	Function
NFS13	Nylon Mesh Filter	13 x 13 in.	-	Primary filtration for visible and coarse particles.
PF13	Pleated Media Filter	13 x 13 in.	0.6 in.	Medium filtration for fine dust.
CF15	Carbon Filter	13 x 13 in.	0.6 in.	Filtration for gases.
HEPA50-33	HEPA (High Efficiency Particulate Air) Filter	13 x 13 in.	2.0 in.	Final filtration for micro particles.
TF12	TiO ₂ Filter	12 x 12 in.	0.4 in.	Kill airborne bacteria.

See Also Page 4: Filters

If your product(s) is not listed above, please visit www.xpowermfr.com for more information.

XPOWER Limited Warranty

1 YEAR LIMITED WARRANTY

XPOWER-branded products purchased in the U.S. from authorized distributors include a 1-year limited warranty. Contact XPOWER to confirm warranty information about your product(s).

This limited warranty covers defects in materials and workmanship in your XPOWER-branded products. Contact an XPOWER Distributor in your region for warranty service and parts replacement.

Items mentioned but not limited to below are not covered by warranty:

- (1) Power cord, filters or any other components considered as a “consumable parts” by XPOWER.
- (2) Normal wear and tear.
- (3) Problems that result, directly or indirectly, at XPOWER’s sole discretion, from:
 - (3.1) External causes such as accident, abuse, misuse or problems with electrical power supply.
 - (3.2) Disassembling, servicing or modification not authorized by XPOWER.
 - (3.3) Usage that is not accordant with product instructions stated in Owner’s Manual.
 - (3.4) Failure to follow the product instructions or lack of necessary maintenance stated in Owner’s Manual.



XPOWER Manufacture, INC.

668 S. 6th Avenue,
City of Industry, CA 91746 USA

Read and save these instructions
www.xpower.com | www.tx-5.com.hk

Index: EU-1-A38
Edition: 1.1.Final